



D3 Trick Ski Mounting Instructions (Inserts front and rear bindings)

Binding Placement

With your foot in the boot or front binding, locate the center of your inside ankle bone (ANKLE centerline). Mark your ANKLE centerline on the binding plate. Next, mark the centerline of your ski.

Traditional Mounting:

For 40"- 42" skis mount the ANKLE centerline **0.25" forward** of the ski centerline.

For 43"- 45" skis mount the ANKLE centerline **0.375" forward** of the ski centerline.


Alternative Mounting:

Alternative - mount the ANKLE centerline up to **0.75" forward** of the ski centerline.

Some skiers doing wake tricks and flips prefer more separation between their feet. Our D3 Reflex Aluminum Trick Plate allows you an additional $\frac{3}{4}$ " of travel to move the front foot forward when compared to traditional Reflex plate designs.

<https://www.d3skis.com/product-p/19425.htm>

DO NOT use plate screws longer than 5/8". USE a hand screwdriver to avoid cross threading of the inserts.



All AIRA trick skis have front boot and rear toe plate machine screw inserts for mounting. Use the inserts only. Do not drill additional holes or screw plates into other areas of the ski. Our D3 Pro Trick Plate (PTP) is designed for maximum rear foot adjustment and fits your skis' rear insert pattern.